


## T-Blade Timber Cutting Schedule & Dimensions

In conjunction with this document we also recommend to read the T-Blade Technical Data Sheet (TDS) available on our website.



Page	Product Code	A Blade Height (mm)	B Base Size (mm x mm)	C Post Size Suitability (mm)	D Bolt Holes	E Thickness (mm)	F Distance between first column and second column of holes (mm)	G Distance from top of blade height to top row holes (mm)	H Distance between top row and bottom row of holes (mm)
2	VBPTB90100	250	80 x 80	90 - 100	M12	10	46	15	95
3	VBPTB115140	275	110 x 110	115 - 140	M16	10	60	25	100
4	VBPTB150180	300	140 x 140	150 - 180	M16	10	90	25	110
5	VBPTB180200	350	180 x 180	180 - 250	M16	10	120	30	160
6	VBPTB250350	400	240 x 240	250 - 350	M20	12	160	40	200





# T-Blade

## Timber Cutting Schedule & Dimensions

### VBPTB115140

#### RECOMMENDED WORKFLOW:


1. Establish centre line based on timber size.  
(**FRONT & SIDE** face)
2. Determine if you are allocating a gap to resist termites, to install the T-Blade Cap, or for the heads of the anchoring bolts. Minimum gap sizes shown.
3. Establish T-Blade height on **FRONT & SIDE** faces.  
(Accounting for gap as required)
4. Measure and cut out blade slot measured from centre line and T-Blade height.  
(**SIDE** face)
5. Measure and cut out 4x bolt holes measured from established centreline and T-Blade height.  
(**FRONT** face)

#### GENERAL NOTES:

- Timber size 140 x 140 mm is for example only. Dimensions are applicable to timber sizes 115 - 140mm.
- Bolt size hole cut-out of 18mm Ø (metric) or 3/4" Ø (imperial) to suit M16 sized bolts.
- Shaded region denotes T-Blade Post Support.
- **VUEBOLT M16 x 110-150mm** is the corresponding size for use with this T-Blade.



technical@bellevuegroup.com.au  
1300 850 520 www.vuetrade.com



# T-Blade

## Timber Cutting Schedule & Dimensions


### VBPTB150180

#### RECOMMENDED WORKFLOW:

1. Establish centre line based on timber size.  
(**FRONT & SIDE** face)
2. Determine if you are allocating a gap to resist termites, to install the T-Blade Cap, or for the heads of the anchoring bolts. Minimum gap sizes shown.
3. Establish T-Blade height on **FRONT & SIDE** faces.  
(Accounting for gap as required)
4. Measure and cut out blade slot measured from centre line and T-Blade height.  
(**SIDE** face)
5. Measure and cut out 4x bolt holes measured from established centreline and T-Blade height.  
(**FRONT** face)

#### GENERAL NOTES:

- Timber size 180 x 180 mm is for example only. Dimensions are applicable to timber sizes 150 - 180mm.
- Bolt size hole cut-out of 18mm  $\varnothing$  (metric) or 3/4"  $\varnothing$  (imperial) to suit M16 sized bolts.
- Shaded region denotes T-Blade Post Support.
- **VUEBOLT M16 x 150-230mm** is the corresponding size for use with this T-Blade.



# T-Blade

## Timber Cutting Schedule & Dimensions

### VBPTB180200


#### RECOMMENDED WORKFLOW:

1. Establish centre line based on timber size.  
(**FRONT & SIDE** face)
2. Determine if you are allocating a gap to resist termites, to install the T-Blade Cap, or for the heads of the anchoring bolts. Minimum gap sizes shown.
3. Establish T-Blade height on **FRONT & SIDE** faces.  
(Accounting for gap as required)
4. Measure and cut out blade slot measured from centre line and T-Blade height.  
(**SIDE** face)
5. Measure and cut out 4x bolt holes measured from established centreline and T-Blade height.  
(**FRONT** face)

#### GENERAL NOTES:

- Timber size 200 x 200 mm is for example only. Dimensions are applicable to timber sizes 180 - 250mm.
- Bolt size hole cut-out of 18mm Ø (metric) or 3/4" Ø (imperial) to suit M16 sized bolts.
- Shaded region denotes T-Blade Post Support.
- **VUEBOLT M16 x 150-230mm** is the corresponding size for use with this T-Blade for timber sizes 180 - 230mm

NOTE: There is currently no corresponding VUEBOLT for timber sizes 230 - 250mm for this T-Blade.



1 ESTABLISH CENTRE LINE

FRONT

1 ESTABLISH CENTRE LINE

SIDE



technical@bellevuegroup.com.au  
1300 850 520 www.vuetrade.com

# T-Blade Timber Cutting Schedule & Dimensions


## VBPTB250350

### RECOMMENDED WORKFLOW:

1. Establish centre line based on timber size.  
(**FRONT & SIDE** face)
2. Determine if you are allocating a gap to resist termites, to install the T-Blade Cap, or for the heads of the anchoring bolts. Minimum gap sizes shown.
3. Establish T-Blade height on **FRONT & SIDE** faces.  
(Accounting for gap as required)
4. Measure and cut out blade slot measured from centre line and T-Blade height.  
(**SIDE** face)
5. Measure and cut out 4x bolt holes measured from established centreline and T-Blade height.  
(**FRONT** face)

### GENERAL NOTES:

- Timber size 300 x 300 mm is for example only. Dimensions are applicable to timber sizes 250 - 350mm.
- Bolt size hole cut-out of 22mm Ø (metric) or 7/8" Ø (imperial) to suit M20 sized bolts.
- Shaded region denotes T-Blade Post Support.
- **VUEBOLT M20 x 230-360mm** is the corresponding size for use with this T-Blade.



1 ESTABLISH CENTRE LINE

FRONT

1 ESTABLISH CENTRE LINE

SIDE



technical@bellevuegroup.com.au  
1300 850 520 www.vuetrade.com

6/6 VUETRADE Timber Connectors is a division of Bellevue Group Australasia.

Bellevue Group Australasia are continuously working to develop and improve our product range. We reserve the right to change specifications, etc. without notice.  
JUN26